ASSEMBLY INSTRUCTIONS



BAR STOOL

www.artleon.com
Email: hello@artleon.com

Be sure to keep spare parts.

**If screws or nails of a product are damaged or lost,
or screws or nails of a subsequent product are
damaged or aged, spare parts can be used to replace them.**

1



Ax1



Bx1


6




Fx1



Ex2





Gx2



Hx2

Install screws G and H to 50%
After screws are installed, tighten them to 100%







SPARE PARTS

If you feel that the chair is not balance
you can adjust the foot nails to level according to your needs







Ax1




Bx1




Cx1




Dx1




Ex2




Fx1



Gx6+1extra
（M6*16mm）



Hx2+1extra
（M6*20mm）




Ix4+1extra
（M6*30mm）




Jx1

3




Dx1

4




Dx1




Gx4


Note: When installing the turntable, please rotate the turntable 45 degrees



Install the 4 screws G to 50% in sequence.
After all the four screws are installed, tighten them to 100%




5




Ex2

2




Cx1



I x4

Note: Accessories E should be placed at the front end, not at the back end



Install the 4 screws I to 50% in sequence.
After all the four screws are installed, tighten them to 100%

Note: When installing Accessory C make sure the drain hole is facing up

