
# ASSEMBLY INSTRUCTIONS



www.artleon.com
Email: hello@artleon.com

## Be sure to keep spare parts.


**If screws or nails of a product are damaged or lost,
or screws or nails of a subsequent product are
damaged or aged, spare parts can be used to replace them.**

7




K×1

If you feel that the chair is not balance
you can adjust the foot nails to level according to your needs.




6



A×1



M6*20MM
G×2


M6*16MM
H×2


I×2



M6
J×1









Install the 4 screws G and H to 50% in sequence.
After all the four screws are installed,tighten them to 100%


# SPARE PARTS


A×1


B×1


C×1


D×4


E×1


M6*30MM

F×4 + 1EXT



M6*20MM

G×10 + 1EXT



M6*16MM

H×2 + 1EXT



I×2



M6

J× 1




K×1

**5**




I×2

**Note:Accessories I should be placed at the front end,not at the back end**



**4**




B×1




M6*20MM
G×4



M6
J×1





**Install the 4 screws G to 50% in sequence.**
**After all the four screws are installed,tighten them to 100%.**

**Fasten All screws indicate on Step 1& Step2.**

**1**



C×1




D×4




M6*20MM
G×4



M6
J×1








**Install the 4 screws G to 50% in sequence.**
**After all the four screws are installed,tighten them to 80%.**

**2**



E×1



M6*30MM


F×4




M6


J×1

**3**



B×1




**Install the 4 screws F to 50% in sequence.**
**After all the four screws are installed,tighten them to 80%.**

**Note:When installing the turntable, please rotate the turntable 45 degrees.**

