

ASSEMBLY INSTRUCTIONS



www.artleon.com
Email: hello@artleon.com

SPARE PARTS



A x 1




B x 1




C x 2




D x 2




E x 1



F x 1



G x 4



H x 1




I x 4+1




J x 18+1




K x 4+1



L x 2+1



M x 2




N x 1



O x 1

1



A x 1



C x 2




D x 2




M6*14MM


I x 4



M4-M6

N x 1





Install the 4 screws | to 50% in sequence.
After all the four screws are installed,tighten them to 80%.

2



B x 1




M6*22MM


J x 8



M4-M6

N x 1





Install the 4 screws J to 50% in sequence.
After all the four screws are installed,tighten them to 80%.

Fasten All screws indicate on Step 1.

3



F x 1



G x 4




M6*22MM


J x 4



M4-M6


N x 1





Install the 4 screws J to 50% in sequence.
After all the four screws are installed,tighten them to 80%.

4



H x 1




M6*30MM


K x 4



M4-M6


N x 1






Install the 4 screws K to 50% in sequence.
After all the four screws are installed,tighten them to 80%.

5




E x 1

Note:When installing the turntable, please rotate the turntable 45 degrees.



6



E x 1




M6*22MM

J x 4



M4-M6

N x 1



Install the 4 screws J to 50% in sequence.
After all the four screws are installed,tighten them to 100%.


Fasten All screws indicate on Step3 & Step4.

7




M x 2

Note:Accessories M should be placed at the front end,not at the back end




8





M6*18MM

L x 2



M6*22MM

J x 2





M x 2



M4-M6

N x 1





Install the 4 screws L and J to 50% in sequence.
After all the four screws are installed,tighten them to 100%

Be sure to keep spare parts.

**If screws or nails of a product are damaged or lost,
or screws or nails of a subsequent product are
damaged or aged, spare parts can be used to replace them.**

9



O x 1

If you feel that the chair is not balance
you can adjust the foot nails to level according to your needs.

