

# ASSEMBLY INSTRUCTIONS



www.artleon.com
Email: hello@artleon.com

**If you feel that the chair is not balance you can adjust the foot nails to level according to your needs**



## Be sure to keep spare parts.

**If screws or nails of a product are damaged or lost, or screws or nails of a subsequent product are damaged or aged, spare parts can be used to replace them.**

# 1



Ax1



Bx1





Cx1



Hx5

**Noted:**
**Tight the screws**
**(H) 50% in Step 1**





# 2





Dx1



Hx4









# 3

**Noted:**
**Tight the screws(H)**
**100% in Step 3**







# 4




Gx4




Jx2



Kx1








5




Fx4

**Last step, please adjust the chair to the horizontal position, otherwise the wooden foot may break risk.**





# SPARE PARTS




Ax1



Bx1



Cx1



Dx1




Ex1




Spare foot p in

Fx1



M6X25mm

Gx4+1Ext




M6X30mm

Hx9+1Ext



5mm thickness
Rubber Washer
Jx2+1Ext



Kx1