
ASSEMBLY INSTRUCTIONS




www.artleon.com
Email: hello@artleon.com


Be sure to keep spare parts.

If screws or nails of a product are damaged or lost, or screws or nails of a subsequent product are damaged or aged, spare parts can be used to replace them.


SPARE PARTS



Ax1



Bx1



Cx1



M8*20
Dx8



Ex4



Fx5**+1**




Gx1



M6*18
Hx4

1



Ax1

8*20
Dx8



Ex4



Fx5



Gx1



6*18
Hx4


2



Ax1




Bx1




Cx1



Gx1





3



Ax1




8*20


Dx8




Gx1



Cx1




4



Bx1



Fx5



5



Ax1



6*18


Hx4




Gx1



Ex4



Bx1



6

